



t: +1.519.659.8373  
tf: +1.800.265.1009  
f: +1.519.659.8306  
JonesHealthcareGroup.com  
3000 Page St. London, ON, Canada N5V 5H3

## Laser Label Storage and Usage Instructions

Please review the following instructions for optimal label performance

### Indoor Storage Conditions



- Store on a level surface, with no elements of the label stock hanging over shelf edges
- Optimal temperature for storage: 17– 26°C (60–80°F)
- Optimal relative humidity for storage: 40 - 60%

### Before Printing



- Use oldest label stock first
- Ensure label stock has been stored at room temperature for at least 24 hours
- Fan all four sides of the label stock
- Ensure printer is set to print on label stock (not paper)
- Refer to your printer operating manual for loading instructions
- **Only load ½ the bundle into the printer tray at a time**
- Do not overload the printer tray above recommended level (check paper guides)

### Proper Usage



- Fold the label along the perforation – all perforations must be pre-folded prior to tearing
- **Label is pressure sensitive - ensure even pressure applied to all edges when applying label to vial**

### Printer Maintenance



For optimal results, ensure your printer is maintained and regularly serviced

